

U2314Uni-Door Towel Dispenser

JOB #:
ITEM #:
QUANTITY:

Revision 03/11

| MOUNTING | HANDING | ТҮРЕ | SIZE | OTHER | | |
|--|--------------------------------------|--------------|--|----------|----------------------------------|--------------------------|
| 17 1/2" 445 mm 15 1/4" 387 mm | | 1 | 4 1/4" | <u>-</u> | 4 1/4" 108 mm 1/4" 6 mm | |
| - - S | S ⁺ 18 1/4" 464 mm 30 76 | 1/4" 8 mm | 70" - 74" / 1778 mm - 1880 mm RECOMMENDED MOUNTING HEIGHT | | +5 | 2 1/4" 57 mm — — — |
| | 12" 305 mm | | | | +8 | |
| | | <u> </u> | | | -SM | - S2 |

SPECIFICATIONS

Cabinet Body: Fabricated of #22 ga stainless steel. Face trim is an integral part of body with a #4 satin finish and 1/4" returns to wall surface for rigidity. One piece construction without miters or welds.

Uni-Door: Fabricated of #18 ga stainless steel with a #4 satin finish with 1/2" returns to wall surface.

Cabinet Back: Fabricated of #22 ga stainless steel with multiple welds to cabinet body:

Towel Dispensing: Hemmed edges that prevent injury and towel tearing. **Hinges:** Heavy duty, full length, stainless steel piano type hinge secured door to cabinet.

Lock: Commercial quality, pin tumbler type lock keyed like all other AJW accessories.

Collars: Fabricated of #22 ga stainless steel finished to match cabinet for surface or recess mounting.

Overall Size: 17 1/2"W x 30 1/4"H x 4 1/4"D

445mm x 762mm x 108mm

Wall Opening: 15 3/4"W x 28 1/2"H x 4"D

400mm x 733mm x 102mm

U2314-S2: 2" semi-recessed collar, 2" wall opening 51mm.

U2314-SM: Full surface mounted collar. **Capacity:** 600 c-fold or 800 multifold

INSTALLATION

Coordinate installation with architect and contractor to avoid interference with pipes vents etc. in wall. Provide a rough wall opening 15 3/4"W x 28 1/2"H. See specification for proper wall depth opening. Open cabinet and insert into wall opening. Secure with proper fasteners per each application. Fill unit with recommended towels, without overfilling. Make sure towels overlap each other so they will be available each time a towel is removed from dispensing area.

Do not use abrasive or chloric solutions when cleaning cabinet.

| N | О. | T | ℸ |
|---|----|---|---|
| | | | |